

DISINFECTANT SOLUTIONS

FROM PLASKOLITE

DISINFECTING ACRYLIC, POLYCARBONATE AND PETG

When disinfecting OPTIX® Acrylic, TUFFAK® Polycarbonate and VIVAK® PETG, proper procedures should be taken. To minimize the risk of damage, use only compatible household

cleaners as outlined below. For more details please contact the Plaskolite Technical Service Group at **800.848.9124** with any questions.

Disinfectants for Plaskolite Products

Product/Brand	Manufacturer	Products	Compatibility**
TUFFAK	sBioMed, LLC	Steriplex SD	Compatible
TUFFAK	Safetec of America	Safetec surface wipes	Compatible
TUFFAK	CONTEC Healthcare	Peridox RTU	Compatible
TUFFAK	CONTEC Healthcare	Prosat sterile wipes PS-911EB	Compatible
TUFFAK	Generic	Hydrogen peroxide 3%-5%	Compatible
TUFFAK	Generic	Isopropyl alcohol 70%	Compatible
TUFFAK	Generic	Contec Sat - Can 120 Satwipes (IPA)	Compatible
TUFFAK	Generic	Warm dish washing soap solution	Compatible
OPTIX	Generic	Hydrogen peroxide 3%-5%	Compatible
OPTIX	Generic	Bleach - household laundry grade	Compatible
OPTIX	Generic	Quaternary ammonium compounds @ use dilution	Compatible
OPTIX	Generic	Isopropyl alcohol - diluted with water to 30% strength	Compatible
OPTIX	Generic	Vital oxide	Compatible
OPTIX	Generic	Warm dish washing soap solution	Compatible
VIVAK	Generic	Hydrogen peroxide 3%-5%	Compatible
VIVAK	Generic	Isopropyl alcohol 70%	Compatible
VIVAK	Generic	Vital oxide	Compatible
VIVAK	Generic	Contec Sat - Can 120 Satwipes (IPA)	Compatible
VIVAK	Generic	Warm dish washing soap solution	Compatible
TUFFAK	The Clorox Company	Clorox® health care bleach germicidal cleaner	Not Compatible
TUFFAK	Unimed Corp	Accel TB	Not Compatible
TUFFAK	The Clorox Company	Clorox® broad spectrum quaternary disinfectant cleaner	Not Compatible
TUFFAK	Zep Inc	ZEP 40	Not Compatible
TUFFAK	Zep Inc	ZEP Spirit II	Not Compatible
TUFFAK	PDI Inc	PDI Super Sani-Cloth	Not Compatible
TUFFAK	Reckitt Benckiser	Lysol disinfectant spray brand III original	Not Compatible
TUFFAK	Fiberlock Technologies Inc	Shockwave disinfectant	Not Compatible
TUFFAK	CONTEC Healthcare	Preempt RTU multi-surface disinfectant cleaner	Not Compatible
TUFFAK	The Clorox Company	Clorox® household bleach - all dilutions	Not Compatible
OPTIX	Generic	Ethyl alcohol - pharmacy grade	Not Compatible

SPECIAL NOTES: Cleaning products were tested on flat, unstressed, uncoated Tuffak Polycarbonate, Optix Acrylic and Vivak PETG sheet products. Do not use incompatible cleaners or disinfectants on sheet products. Generally speaking, soap and water or hydrogen peroxide disinfectants work best on these products.

**Because manufacturers sometimes change their formulas without notification compatibility in perpetuity can not be presumed.

These suggestions and data are based on information we believe to be reliable. They are offered in good faith, but without guarantee, as conditions and methods of use are beyond our control. We recommend that the prospective user determine the suitability of our materials and suggestions before adopting them on a commercial scale.

PLASKOLITE

400 Nationwide Blvd, Suite 400
Columbus, OH 43215
800.848.9124 • Fax: 877.538.0754
plaskolite@plaskolite.com
www.plaskolite.com

DISINFECTANT SOLUTIONS

FROM PLASKOLITE

These general guidelines are focused on household cleaners and are meant for the general public. Following the suggested guidelines may result in reducing the survival of bacteria and viruses in these environments, however the risk of transmission is always present.

- » **Cleaning** refers to the removal of germs, dirt, and impurities from surfaces. It does not kill germs, but by removing them, it lowers their numbers and the risk of spreading infection.
- » **Disinfecting** refers to using chemicals, for example, EPA-registered disinfectants, to kill germs on surfaces. This process does not necessarily clean dirty surfaces or remove germs, but by killing germs on a surface **after** cleaning, it can further lower the risk of spreading infection.
- » Wear disposable gloves when cleaning and disinfecting surfaces. Gloves should be discarded after each use.
- » If surfaces are dirty, they should be cleaned using a gentle warm dish washing soap and rinsed with clean water prior to disinfection.
- » Use of microfiber cloths cleans 50% better than comparable cotton towels and reduces the risk of scratching plastic.
- » Allow enough **contact time** after applying the disinfectant. If the contact time is too brief, the surface will not be thoroughly disinfected.

BLEACH - Compatible with Optix® Acrylic, Vivak® PETG

- » Prepare a household bleach solution by mixing:
 - 5 tablespoons (1/3 cup) bleach per gallon of water.
 - 4 teaspoons bleach per quart of water.
- » Diluted bleach is not stable and should be prepared weekly from concentrated stock.
- » Follow manufacturer's instructions for application - contact time typically measured in minutes.

ISOPROPYL ALCOHOL [IPA] or ETHYL ALCOHOL - Compatible with Vivak PETG, TUFFAK® Polycarbonate

- » Use of alcohol-based wipes or sprays or soaked cloths containing at least 70% alcohol.
- » Do not dilute.
- » Fast acting. Allow alcohol to remain on surface for at least 30 seconds or longer to disinfect.

HYDROGEN PEROXIDE - Compatible with Optix Acrylic, Vivak PETG, TUFFAK Polycarbonate

- » Use 3-5% hydrogen peroxide.
- » Do not dilute.
- » Allow to remain on the plastic for several minutes.

WARM SOAPY WATER - Compatible with Optix Acrylic, Vivak PETG, TUFFAK Polycarbonate

- » The use of warm, gentle dish soap is a common form of cleaning and disinfecting.
- » Thoroughly and vigorously wash the surface of the plastic with dishwashing soap for a minimum of 20 seconds or longer.
- » Rinse with clean water.

The chemical resistance of Plaskolite products depends on the concentration of the cleaner/disinfectant, contact time, temperature of the solution and plastic, and stress level of the part. Repeated and/or extended chemical exposures, heat, elevated stress or any combination of these conditions could degrade the plastic or its chemical resistance. Therefore, it is imperative that the plastic be inspected routinely for chemical attack and overall degradation, and replaced as needed, similar to other forms of protective equipment such as masks, gloves, safety shields and barriers.

Plaskolite has prepared these guideline summaries as a service to our customers, based on available information from public health authorities and our own internal knowledge of Plaskolite products. Even if the sanitizing methods described are fully and correctly implemented, we cannot guarantee that they will be effective to prevent the transmission of any disease or infectious agent. Plaskolite makes no warranty or representation regarding the quality, currency, accuracy, or reliability of any information regarding appropriate infection control practices.

Reference: <https://www.cdc.gov/coronavirus/2019-ncov/prevent-getting-sick/cleaning-disinfection.html>